

# 5' x 7' Overlap Apex Shed

IMPORTANT, RETAIN FOR FUTURE REFERENCE; READ CAREFULLY

This building is pre-treated with a factory base coat for protection during storage and transit. We recommend that you treat your new building as soon as possible after assembly using a wood preservative treatment. Apply in accordance with the manufacturers instructions.

- This product must be built on a solid level base.
- The roof of this building is not a load bearing structure.
- Timber is a natural material. It will shrink and swell as a result of varying moisture content.
- Due to the nature of the material the doors may need some trimming for a neater fit.
- Please keep all plastic bags and small parts away from children

Technical Helpline: **0333 7777 089** 8.30 am and 5.00 pm Monday to Friday.


## Please check all parts prior to assembly

Assembly of damaged parts may be deemed to be acceptance and this may affect the remedies you are entitled to. If the product is not constructed in accordance with the instructions, or is altered in any way (e.g. painted), the manufacturer cannot be held liable for any resulting damage.


### Fixing Pack (ODA68FP)

This fixing pack is used for several products. There may be additional fixings.

Not to Scale




Hasp & Staple



L' bracket Qty 6



Flush Hinge Qty 2



### REQUIRED TOOLS : (NOT SUPPLIED)



POZI DRIVE SCREWDRIVER



FLAT HEAD SCREWDRIVER



SHARP KNIFE



HAMMER



TAPE MEASURE





SCISSORS

Important : Assembly of this shed requires a minimum of two adults.



## ODA57 PARTS LIST




Place the panels on top of the floor. Make sure that all the panels are tight and flush before fixing them to each other using 3x50mm screws.


When the panels are secured to each other, make sure that they are square before securing them to the floor. Fix the sides to the floor using a 2 x L' brackets and 8 x 25mms screws for each positioned as shown.

Fix the door end with 3 x 50mm screws making sure these locate into the floor bearer.

(when positioning the brackets make sure these are in line with the floor bearers underneath.)




Fix the 20 x 1585mm strip to the side of the door frame so that it is tight with the cladding and flush with the frame. Use 4 x 30mm nails.



Place the hinge against the inside of the door frame and position the large section of the hinge so that it is flush with the inside of the framing as shown. Fix with 25mm screws.


Open the hinge and fix the smaller section to the door framing. Again make sure that the hinge is flush and that the holes are positioned so that the 25mm screws locate correctly into the batten.




Place the 2038mm batten so that it sits at the apex and bridges between the plain end and door end. Fix the batten in place using an L' bracket and 4 x 25mm screws for each end.

Position each corner strip so that it is flush with the panel and covers the joins. Fix each in place using 4 x 30mm nails.

5




Attention:  
Take care when placing the screws. These can not be backed out.




Place the window from the outside so that the lip sits on the bottom board as shown.  
Fix each sheet in place using 2 x security screw at the side and top.  
Fix the 650mm strip vertically between the two window sheets so that it overlaps both sides. Fix this to the framework using 2 x security screws.

6





Place a roof board onto two of the 1035mm battens making sure that the board is flush on all sides. The battens should run along one long edge of the roof only. Fix the battens in place using 4 x 20mm nails for each.

7




Lift the roof sections into place making sure that they are in line with the apex and the front and back panels of the shed.  
Fix the roof section in place using 3 x 25mm screws at each end, and 1 x 30mm screw at each side. Make sure the screws locate into the framing.  
Repeat for the other roof section.

8



Unroll the felt and cut it in to two equal lengths. Place the sheets on each side so that there is a 50mm overhang on the eaves and they overlap at the apex. Fix these to the roof using felt nails spaced in 150mm intervals. Cut and fold the corners securing with a single felt nail for each.




9



Attention  
Take care when cutting and trimming the roof felt.

Place the barge boards against the ends of the shed so that they are flush with the overhang of the roof and in line with the top. Fix each in place using 4x30mm nails.  
Place the finials over the join making sure that they are centred. Secure in place using 2x30mm nails.  
Trim off any excess felt using a sharp knife.

10



Before fixing the Hasp to the door make sure that it is in line with the framing on the reverse and is positioned so that it will close over the Staple. Fix this in place using 3 x 25mm screws.  
Position the Staple opposite, again making sure that it is in line with the framing behind and fix it in place using 2 x 25mm screws.

**Biocidal Product Regulation (EU 528/2012) Article 58 Information**

This article contains timber treated with Celcure AC-500, incorporating biocidal products to give protection against wood destroying insects & wood rotting fungi.

**Contains:** Basic copper carbonate (Copper (II) carbonate – Copper (II) hydroxide (1:1)), Boric acid, Benzalkonium chloride.

Wear gloves when handling freshly treated wood. Avoid breathing dust when cutting treated or untreated wood. Dispose of off-cuts responsibly – do not burn.

**Maintenance.**

We recommend that you treat your shed at the beginning of each season with a wood preservative treatment. Apply in accordance with the manufacturers instructions.

Regularly check all fixings are secure.