

3' x 5' Value Shed

IMPORTANT, RETAIN FOR FUTURE REFERENCE;
READ CAREFULLY

Check all parts prior to assembly

This building is pre-treated with a factory base coat for protection during storage and transit. We recommend that you treat your new building as soon as possible after assembly using a wood preservative treatment. Apply in accordance with the manufacturers instructions.




- Timber is a natural material. It will shrink and swell as a result of varying moisture content.
- Please keep all plastic bags and small parts away from children
- This product must be built on a solid level base.
- The roof of this product is not a load bearing structure.

Technical Help line: **0333 321 3142** 8.30 am to 5.00 pm Monday to Friday.



In line with your statutory rights, please check all parts prior to assembly, as assembly of damaged parts may be deemed to be acceptance and this may affect the remedies you are entitled to. If the product is not constructed in accordance with the instructions, or is altered in anyway (e.g. painted), the manufacturer cannot be held liable for any resulting damage.

Fixing Pack (VOL35FP)

Not to Scale




ODA3D5NW PARTS




Place and secure two hinges to the door so that they line up with the battens on the reverse using 4x30mm (black) screws for each.

Place the door into the door end ensuring that it is square. Fix the doors in place using 3x30mm (black) screws for the other section of each hinge.




Place the 1506mm batten so that it sits on the framework at the apex of both the plain end and door end as shown. Fix this in place using 1 x 60mm screw for each end. (Make sure you pre-drill).




Place the panels on top of the floor. Make sure that all the panels are tight and flush before fixing them to each other using 3x50mm screws.

When the panels are secured to each other, ensure that they are square before securing them to the floor. Secure the door end to the floor using 1 x 50mm screws making sure it locates into the floor bearer. Fix the plain sides to the floor using the L' brackets. Position these side ways and make sure they are in line with the floor bearers underneath. Fix each in place using 4 x 25mm screws.



Place the corner strips so that they cover the joints between the panels. Fix each in place using 3 x 25mm screws.


5



Place the roof board onto a 1540mm batten making sure that the board is flush on all sides. Fix the batten in place using 4 x 25mm screws.

Repeat for the other roof section.

6





Lift the roof sections into place ensuring that they are in line with the apex and the front and back panels of the shed.

Fix the roof section in place using 3 x 25mm screws for each end and 3 x 30mm screws for the sides. Make sure the screws locate into the framing.

Repeat for the other roof section.

7





Unroll the felt and cut it into two equal lengths. Place each section so that they overlap at the apex and overhang on the eaves by approximately 50mm. Fix the felt to the roof using felt nails spaced in 150mm intervals along the edges and the seam. Make sure that the felt nails are positioned so that each locates into the batten on the eaves. Cut and fold the corners securing with a single felt nail.

Attention

Take care when cutting and trimming the roof felt

8



Place the barge boards against the ends of the shed so that they are flush with the overhang of the roof and in line with the top. Fix each in place using 3x30mm screws.

Place the finials over the joins making sure they are centred. Secure in place using 2x30mm screws for each. (Make sure you pre-drill)

Trim off any excess felt that may protruding beneath the barge boards.

Biocidal Product Regulation (EU 528/2012) Article 58 Information

This article contains timber treated with Celcure AC-500, incorporating biocidal products to give protection against wood destroying insects & wood rotting fungi.

Contains: Basic copper carbonate (Copper (II) carbonate – Copper (II) hydroxide (1:1)), Boric acid, Benzalkonium chloride.

Wear gloves when handling freshly treated wood. Avoid breathing dust when cutting treated or untreated wood. Dispose of off-cuts responsibly – do not burn.

Maintenance.

We recommend that you treat your shed at the beginning of each season with a wood preservative treatment. Apply in accordance with the manufacturers instructions.

Regularly check all fixings are secure.